

CCQ

Ceramic, Concrete & Quarry Tile Cleaner

Use Directions

Maintenance Cleaning

Use 1L CCQ per 40 litres of water

Auto Scrubbers

Use 1L CCQ per 100 litres of water

Initial Cleans

Use 1L CCQ per 5 litres of water

Rinse product contacting surfaces with water after use.

Do not use CCQ on aluminium or polished floors.

Packages

2x5L